

## Rotary Function List

ADF1\_ACTIVE  
ADF1\_STANDBY  
ADF2\_ACTIVE  
ADF2\_STANDBY  
ADF1\_CARD  
ADF2\_CARD  
COM1\_ACTIVE  
COM1\_STANDBY  
COM2\_ACTIVE  
COM2\_STANDBY  
DME\_ACTIVE  
DME\_STANDBY  
NAV1\_ACTIVE  
NAV1\_STANDBY  
NAV2\_ACTIVE  
NAV2\_STANDBY

AILERON\_TRIM  
ALTIMETER  
AP\_ALTITUDE\_ADJ  
AP\_NAV\_COURSE\_ADJ  
AP\_HEADING\_ADJ  
AP\_SPEED\_ADJ  
AP\_VERT\_SPEED\_ADJ  
APU\_SWITCH  
BLEED\_AIR\_MODE  
COCKPIT\_LTS  
DECISION\_HEIGHT  
DISP\_BRIGHTNESS  
EFIS\_ND\_MODE\_SEL  
EFIS\_ND\_SUB\_MODE\_SEL  
EFIS\_ND\_RANGE\_SEL  
ELEV\_TRIM  
HSI\_SELECTOR  
HUD\_BRIGHTNESS  
INST\_BRIGHTNESS  
NAV\_COM\_ADF\_MODE  
OBS1  
OBS2  
RMI\_SELECTOR  
ROTOR\_TRIM  
RUDDER\_TRIM  
TRANSPONDER\_MODE  
XPDR